


ADP - 37

*ADAPTER FOR UNIVERSAL USE OF SHUTTER CAMERA


← MONITOR

NOTE!

The shutter from the camera will open automatically when the yellow trigger wire from the ADP-37 is activated by DC10~32V



- CONNECTION



- CONNECTOR PIN DESCRIPTION

